




Fitting Instructions
YewdaleKestrel[®]
SafeArt

Part no: 1028


SafeArt Instructions

01




02

Attach mounting plates to wall using anti-tamper security screws.




03



04

Test installation

The downward force need to part SafeArt from its mounting plate should never be more than 9kg at any point.



SafeArt

Warning

- The magnetic element of the YewdaleKestrel® bracket is **powerful**. Handle with care. If attached to a flat steel surface, it may be difficult to remove the magnet. **DO NOT PLACE NEAR SENSITIVE ELECTRONIC EQUIPMENT.**
- YewdaleKestrel® products are designed as standalone products only. Care should be taken when assessing or arranging a room to ensure that YewdaleKestrel® products cannot be misused in conjunction with any other item, furniture or fixings in the room.
- It is the responsibility of the end user or client to ensure the product is suitable for the environment it is being installed in. YewdaleKestrel® products must be fitted by a qualified professional following the manufacturer's instructions. Failure to do so could jeopardise the product's effectiveness as an anti-ligature system. All installations must be checked and commissioned on completion to ensure the downward forces does not exceed the maximum nor that it is breaking away below the normal force. It is highly recommended that sign off proof that the product is installed and commissioned correctly is issued to the client after installation.



For more information on installations, using the systems safely, load testing and maintenance, please scan the QR code to read our YewdaleKestrel® Policy.



Head Office:

Enterprise Way,
Wickford, Essex, SS11 8DH
Call: +44 (0)1268 570900
Email: sales@yewdale.co.uk

London Office & Showroom:

4 Sutton Lane,
London, EC1M 5PU
Call: +44 (0)203 818 5905

For more information on all
Yewdale products, please call
the sales department.

