



SafeArt

Features:

SafeArt allows mental health trusts to display calming images without creating ligature points. Available in 6 sizes, SafeArt is constructed from soft foam. The product mounts to most surfaces via load release magnets which separate from the wall when subjected to a load greater than 9kgs.

Benefits:

Choose from a range of vibrant, calming images intended to reduce anxiety and increase comfort. The soft foam is reinforced by fibreglass, which adds strength and ensures the print quality is exceptional and long-lasting.

The load release magnets are securely sewn into tamper-resistant pockets located on the rear of the product. A stainless steel mounting plate is fitted to the wall, providing the magnets with a fixing point.

The 3mm thick mounting plate cannot be removed from the wall without specific tools and features rounded edges to prevent ligature risk. Due to the magnetic fixing, SafeArt is interchangeable. Different SafeArts can be swapped within a building to introduce new images to various areas. The soft foam material poses minimal risk of injury and ensures the product will not sustain damage if it falls. Anti-microbial (BioSafe) material is fire resistant and easily cleaned.

Options:

Small, medium and large artwork sizes are available.

Small:

305mm x 305mm or 457mm x 457mm

Medium:

610mm x 610mm or 610mm x 762mm

Large:

915mm x 915mm or 915mm x 1067mm

Specification:

The magnetic anti-ligature YewdaleKestrel® SafeArt with vandal resistant, soft foam core as manufactured by Yewdale, +44 (0)1268 570900. Manufactured from flame retardant fabric, constructed using anti-pick, tamper resistant materials, and incorporating Biosafe antibacterial formula to withstand vigorous daily use in hospital and mental health environments. The tear/stain resistant SafeArt is anti-static and will fall away from its magnetic fixing plates when subjected to a load greater than 9kgs.

O+M Guidance

It is an NHS requirement that items suspended on load-release support systems should be maintained and load-tested in accordance with the manufacturer's instructions on an annual basis. The YewdaleKestrel® system's performance remains constant even after repeated use. It is a requirement, however, to carry out a physical inspection and testing of YewdaleKestrel® fittings to identify any possible damage or evidence of tampering and undertake an annual load test.

For full compliance and product warranty, annual inspection and load testing of YewdaleKestrel® systems should be carried out by Protects Plus 0345 646 0955. If testing is carried out by others the liability would remain with them and/or the healthcare provider and any warranty is void.

Safety Note:

Sensitive electronic equipment may be damaged by proximity to a magnetic field and should not come within 150mm of the underside of the brackets. Any load-release device, by its nature, may cause damage when operated. Articles suspended from the YewdaleKestrel® magnetic anti-ligature system will come down when pulled.

YewdaleKestrel® products are designed as standalone products only. Care should be taken when assessing or arranging a room to ensure that YewdaleKestrel® products cannot be misused in conjunction with any other item, furniture or fixings in the room. It is the responsibility of the end-user or client to ensure the product is suitable for the environment it is being installed in. YewdaleKestrel® products must be fitted by a qualified professional following the manufacturer's instructions. Failure to do so could jeopardise the product's effectiveness as an anti-ligature system.



For more information on installations, using the systems safely, load testing and maintenance, please scan the QR code to read our YewdaleKestrel® Policy.